



PR015

ACTIVE SPEAKER BOX

USER MANUAL

IMPORTANT INSTRUCTION

For your own safety please read this user manual carefully before installing the device.

SAFETY INTRODUCTION

*If this speaker has been exposed to significant temperature changes due to storage or transportation changes, do not switch it on immediately. Leave the speaker switched off until it has reached room temperature.

*It is essential that the device is earthed. A qualified person must carry out the electric connection.

*Make sure that the available voltage is not higher than stated at the end of this manual.

*Make sure the power cord is never crimped or damaged before and during use.

*Only handle the power cord by plug. Never pull out the plug by tugging the power cord.

*Turn off power before disconnecting electric.

CAUTION

1. Please be aware that damages caused by user modification, misuse, physical abuse or any unusual activities will void the warranty.
2. Use this speaker at safe listening volumes.

CAUTION GENERAL GUIDELINES

*Operate this speaker only after reading this user manual.

*Please use the original packaging if the device is to be transported.

*For safety reasons, do not remove any speaker components or rear panel.

PRO15 SPECIFICATION

Model	PRO15
LF Woofer	15" ,3"VC ,70oz Magnet 8ohm
HF Woofer	44mm,1.75"Titanium
Frequency Response	50 Hz – 18 kHz
Enclosure Material	Plastic
Grille	Steel
Power	1400W Peak
Amplifier	Class D with FIR DSP
Max SPL	134 dB
Input signal	bal/unbal
Input connectors	Combo XLR/Jack
Output connectors	XLR
Protections	Thermal
Limiter	Soft Limiter
Height	440mm
Width	440mm
Depth	720mm
Weight Net	21. 55kgs