



G15

ACTIVE COLUMN SPEAKER

USER MANUAL

IMPORTANT INSTRUCTION

For your own safety please read this user manual carefully before installing the device.

SAFETY INTRODUCTION

*If this speaker has been exposed to significant temperature changes due to storage or transportation changes, do not switch it on immediately. Leave the speaker switched off until it has reached room temperature.

*It is essential that the device is earthed. A qualified person must carry out the electric connection.

*Make sure that the available voltage is not higher than stated at the end of this manual.

*Make sure the power cord is never crimped or damaged before and during use.

*Only handle the power cord by plug. Never pull out the plug by tugging the power cord.

*Turn off power before disconnecting electric.

CAUTION

1. Please be aware that damages caused by user modification, misuse, physical abuse or any unusual activities will void the warranty.
2. Use this speaker at safe listening volumes.

CAUTION GENERAL GUIDELINES

*Operate this speaker only after reading this user manual.

*Please use the original packaging if the device is to be transported.

*For safety reasons, do not remove any speaker components or rear panel.

SPECIFICATIONS

Model	G15
Subwoofer	15" x 1
Column	4" x 6, Horn 2.5" VC 1" x 1
Amplifier	Class D
Total Power	700W RMS / 1400W PEAK
Frequency Response	40 Hz - 20 kHz
Impedance	4 ohm
Resonance per speaker (Hz)	15" : 40 Hz / 4" 120 Hz
Max SPL	131 dB SPL
Material	Subwoofer :15mm Plywood Column speaker :Plastic
Weight	35 KG