PRO18

ACTIVE SUBWOOFER

USER MANUAL

IMPORTANT INSTRUCTION

For your own safety please read this user manual carefully before installing the device.

SAFETY INTRODUCTION

*If this speaker has been exposed to significant temperature changes due to storage or transportation changes, do not switch it on immediately. Leave the speaker switched off until it has reached room temperature.

*It is essential that the device is earthed. A qualified person must carry out the electric connection.

*Make sure that the available voltage is not higher than stated at the end of this manual.

*Make sure the power cord is never crimped or damaged before and during use.

*Only handle the power cord by plug. Never pull out the plug by tugging the power cord.

*Turn off power before disconnecting electric.

CAUTION

1. Please be aware that damages caused by user modification, misuse, physical abuse or any unusual activities will void the warranty.
2. Use this speaker at safe listening volumes.

CAUTIOGENERAL GUIDELINESN

*Operate this speaker only after reading this user manual.

*Please use the original packaging if the device is to be transported.

*For safety reasons, do not remove any speaker components or rear panel.

PRO18 SPECIFICATION

Model	PRO18
LF Woofer	18'', 4''VC,125oz Magnet 8ohm
Frequency Response	40Hz-200Hz
Enclosure Material	Plywood
Grille	Steel
Power	1000W RMS / 2000W Peak
Amplifier	Class D with FIR DSP
Max SPL	133dB
Input signal	bal/unbal
Input connectors	Combo XLR/Jack
Output connectors	XLR
Protections	Thermal
Limiter	Soft Limiter
Height	775mm
Width	625mm
Depth	810mm
Weight Net	48kgs